



Computer Networks Fundamentals

Basic Network Elements (Software)

TCP/IP Protocol Suite

Basic Network Elements (Software)

TCP/IP

- **Transmission Control Protocol/Internet Protocol.**
- TCP/IP is **open standard protocol**
 - Not tied to one vendor
- TCP/IP is the internet protocol
- Now internet use **TCP/IP v4**
- Next version **TCP/IP v6**
- It is the **default** protocol for all modern operating systems
 - Microsoft Operating Systems
 - UNIX Operating Systems
 - LINUX Operating Systems

Basic Network Elements (Software)

TCP/IP Advantages and Disadvantages

- Advantages
 - Standard
 - Direct access to the Internet
 - Routable
 - Cross Platform
- Disadvantages
 - Difficulty of setup
 - Slower than other protocols like IPX/SPX & NetBEUI

Basic Network Elements (Software)


Major Networking Protocols

- ◊ TCP/IP _ free / standard
- ◊ IPX/SPX _ by Novel/ not free/not standard
- ◊ NetBEUI – not routable
- ◊ Apple Talk
- ◊ Data Link Control (DLC)

Basic Network Elements (Software)

TCP/IP VS. OSI Model


- Defines four layers
- Uses different names for Layers 1 through 3
- Combines Layers 5 through 7 into single application layer



Basic Network Elements (Software)


Data Encapsulation

Protocol Operation of Sending and Receiving a Message



Basic Network Elements (Software)


Some Protocols in TCP/IP Suite



Basic Network Elements (Software)

TCP/IP Protocol Architecture


- Network Access Layer
 - **Physical Layer**
 - Transmission medium
 - Signal rate
 - **Datalink Layer**
 - Logical interface between end system and network
 - Hop to Hop addressing
 - Error detection Mechanism




Basic Network Elements (Software)

Physical (Mac) Addresses

- **Physical Address** burned on the card
- **Unique** address over the world
- called Mac address.
- **48-bit** (6-byte) written as **12 hexadecimal** digits; every byte (2 hexadecimal digits) is separated by a colon :
00-50-56-C0-00-01
- Physical addresses can be either
 - **unicast**
 - **multicast**
 - **broadcast**



Communicating Within the LAN



301P_075

Basic Network Elements (Software)- LAB

Physical Addresses

- To check your physical address: -
 - ❑ **Ipconfig /all**
 - ❑ **GetMac**

```
Connection-specific DNS Suffix . : 
Description . . . . . : Qualcomm QCA61x4A 802.11ac Wireless Adapter
Physical Address . . . . . : 74-40-BB-80-37-3D
DHCP Enabled. . . . . : Yes
Autoconfiguration Enabled . . . . . : Yes
IPv6 Address. . . . . : fd9c:c172:b05a:8700:bc38:bbc1:e959:4f54(Preferred)
Temporary IPv6 Address. . . . . : fd9c:c172:b05a:8700:e597:12c5:be0:3a7c(Preferred)
Link-local IPv6 Address . . . . . : fe80::bc38:bbc1:e959:4f54%18(Preferred)
IPv4 Address. . . . . : 192.168.1.2(Preferred)
Subnet Mask . . . . . : 255.255.255.0
Lease Obtained. . . . . : Saturday, September 28, 2019 9:12:55 AM
Lease Expires . . . . . : Sunday, September 29, 2019 9:12:53 PM
Default Gateway . . . . . : 192.168.1.1
DHCP Server . . . . . : 192.168.1.1
DHCPv6 IAID . . . . . : 108282043
DHCPv6 Client DUID. . . . . : 00-01-00-01-22-DA-1F-5D-54-BF-64-2B-09-81
DNS Servers . . . . . : 192.168.1.1
                                         192.168.1.1
NetBIOS over Tcpip. . . . . : Enabled

Tunnel adapter Teredo Tunneling Pseudo-Interface:
```

Example Physical Address
07:01:02:01:2C:4B

```
C:\Users\ITD-mabdsalam>getmac


Physical Address      Transport Name
===== =====
74-40-BB-80-37-3D    \Device\Tcpip_{AF590558-C7CC-40B4-95A4-9F4476D1DDEC}
54-BF-64-2B-09-81    Media disconnected
N/A                  Hardware not present
00-50-56-C0-00-01    \Device\Tcpip_{D37FF6B5-F7BA-498B-979F-AE0B4A6B42E1}
00-50-56-C0-00-08    \Device\Tcpip_{AA96FF0D-8253-4B8C-9233-DD61B6501B22}

C:\Users\ITD-mabdsalam>
```

Basic Network Elements (Software)

Internet Layer (IP Layer)

- **Network layer protocol**
- Packet in the IP layer is called **Datagram**
- Datagram consist of TWO parts
 - Header
 - Data
- Routing of data
- Logical addressing IPV4 , IPV6



Basic Network Elements (Software)

Internet Protocol (IP V4)

- Uniquely identify each device on an IP network layer.
- Some times we called it the **logical address**
- Every host (computer, networking device, peripheral) must have a **unique address** at the same network
- The IP address **32 bit** divided into **4 octets** each octet 8 bit

Basic Network Elements (Software)

IP Address Format: Dotted Decimal Notation

32 Bits					
		Example			
An IP address is a 32-bit binary number		10101100000100001000000000010001			
For readability, the 32-bit binary number can be divided into four 8-bit octets		10101100	00010000	10000000	00010001
Each octet (or byte) can be converted to decimal		172	16	128	17
The address can be written in dotted decimal notation		172.	16.	128.	17

301P_311

1 octet = 8 bit each represents from 0 to 255 separated with dots

- The address space of IPv4 is 2^{32} or 4,294,967,296**

Basic Network Elements (Software)

IP ADDRESS RANGES

IP Address Class	First Octet Binary Value	First Octet Decimal Value	Possible Number of Hosts
Class A	1-126	<u>0</u> 0000001 to <u>0</u> 1111110*	16,777,214
Class B	128-191	<u>1</u> 0000000 to <u>1</u> 0111111	65,534
Class C	192-223	<u>11</u> 000000 to <u>11</u> 011111	254

30IP-500

IP Address Classes: The First Octet

A B C ... Easy as 1 2 3

Class A ... First 1 bit fixed	<u>0</u> x x x x x x x . Host . Host . Host
Class B ... First 2 bits fixed	<u>10</u> x x x x x . Network . Host . Host
Class C ... First 3 bits fixed	<u>110</u> x x x x . Network . Network . Host
Class D <u>1110</u> Multicast address	Class D 224.0.0.0 Multicast Address
Class E <u>1111</u> Reserved for future use	Class E 240.0.0.0 Reserved
	239.255.255.255 Multicast Address
	255.255.255.255 Reserved

Basic Network Elements (Software)

PUBLIC IP ADDRESSES (REAL IP)

Class	Public IP Ranges
A	1.0.0.0 to 9.255.255.255 11.0.0.0 to 126.255.255.255
B	128.0.0.0 to 172.15.255.255 172.32.0.0 to 191.255.255.255
C	192.0.0.0 to 192.167.255.255 192.168.0.0 to 223.255.255.255

Private IP Addresses (Local IP)

Class	Private Address Range
A	10.0.0.0 to 10.255.255.255
B	172.16.0.0 to 172.31.255.255
C	192.168.0.0 to 192.168.255

- **Nat** is used to Translate the private IP address to public IP addresses.


Basic Network Elements (Software) - LAB

- To know your real IP addresses

<https://www.whatismyip.com/>

- To get bulk of the Public IP address you get it from your service provider

- With the grow the of the public IP address we used NAT and IPV6



Basic Network Elements (Software) - LAB

❖ Ipconfig

Ipconfig is a command line utility in Microsoft Windows.

ipconfig allows you to get the IP address information of a Windows computer

MAC Address

IP address


Default gateway

Subnet mask

DNS server

❖ To know your Private IP addresses

- Ipconfig
- Ipconfig /all
- Ipconfig /release
- Ipconfig /renew



```
C:\WINDOWS\system32\cmd.exe
C:\Documents and Settings>ipconfig /all

Windows IP Configuration

Host Name . . . . . : PCUSER
Primary Dns Suffix . . . . . :
Node Type . . . . . : Hybrid
IP Routing Enabled. . . . . : No
WINS Proxy Enabled. . . . . : No
DNS Suffix Search List. . . . . :

Ethernet adapter Local Area Connection:

Connection-specific DNS Suffix . . . . . : Intel(R) PRO/1000 MT Desktop Connection
Description . . . . . : Intel(R) PRO/1000 MT Desktop Connection
Physical Address. . . . . : 00-15-58-2F-21-E6
Dhcp Enabled. . . . . : Yes
Autoconfiguration Enabled . . . . . : Yes
IP Address. . . . . : 192.168.1.102
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.1.1
DHCP Server . . . . . : 192.168.1.1
DNS Servers . . . . . : 127.107.241.185
                                         127.135.250.69
Lease Obtained. . . . . : Wednesday, April 25, 2007 12:27:51 AM
Lease Expires . . . . . : Thursday, April 26, 2007 12:27:51 AM
```


Basic Network Elements (Software) - LAB

❖ How to assign IP address to device

- Manually
- Automatic
- APIPA

- Set IP address
- Set Subnet mask
- Set IP default-Gateway
- Set DNS server

- Manually




Basic Network Elements (Software) - LAB

❖ Assign IP address Automatic

■ DHCP Server

- used to assign dynamically the IP Configuration including (Host IP, Subnet mask, Default Gateway, DNS server IP and the Lease Time)
- **Dora** (discover –offer-request- acknowledgment)




Basic Network Elements (Software) - LAB

❖ Assign IP address Automatic

■ APIPA (Automatic Private IP Address)

- If **no DHCP server** is available the APIPA is used
- Auto configuration IP address
- used to let LAN users talk to Each other if the DHCP fails
- Can **not** be Routed
- **Rang : 169.254.0.0 To 169.254.255.255**

■ APIPA




Basic Network Elements (Software) - LAB

❖ ICMP → Ping

- Ping is a command line utility in Microsoft Windows.
- Ping allows you to check connectivity with other devices
- Ping is a tool of DOS attack

❖ Tray in your lab

- Ping IP
- Ping URL
- Ping IP -l
- Ping IP -n
- Ping IP -t



```
Microsoft Windows [Version 10.0.16299.967]
(c) 2017 Microsoft Corporation. All rights reserved.

C:\Users\ITD-mabdsalam>ping 127.0.0.1

Pinging 127.0.0.1 with 32 bytes of data:
Reply from 127.0.0.1: bytes=32 time<1ms TTL=128

Ping statistics for 127.0.0.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\Users\ITD-mabdsalam>
C:\Users\ITD-mabdsalam>
```

Basic Network Elements (Software)

RESERVED ADDRESS

❖ **Network address:**


- reserved
- can not be assigned to any device
- used for routing by the router

Class A:10.0.0.0

Class B: 172.16.0.0

Class C:192. 168.1.0

■ Network Addresses




Basic Network Elements (Software)

RESERVED ADDRESS

Loop back Address


- Loopback address: It is used just for testing
- the TCP/IP Protocol Suit
127.0.0.1 example test NIC




Basic Network Elements (Software)

DELIVERY OF IP PACKETS

Direct delivery




Indirect delivery



Basic Network Elements (Software) - LAB

Network Address Translation(NAT)


The technology allows a site to use a set of private addresses for internal communication and a set of global Internet addresses (at least one) for communication with the rest of the world



Basic Network Elements (Software) - LAB

❖ ARP (ADDRESS RESOLUTION PROTOCOL)

Arp -a



ARP TABLE


```
C:\WINNT\system32\cmd.exe
D:\>arp -a

Interface: 192.168.1.101 on Interface 0x10000003
Internet Address      Physical Address      Type
192.168.1.1           00-04-5a-22-ec-c7    dynamic
192.168.1.40          00-02-4b-cc-d6-d9    dynamic
192.168.1.42          00-02-fd-65-9f-82    dynamic
192.168.1.43          00-03-6b-09-59-29    dynamic
192.168.1.100         00-02-4b-cc-d6-d0    dynamic
192.168.1.135         00-03-6d-1e-6a-a5    dynamic
192.168.1.149         00-50-8b-f7-cf-59    dynamic


D:\>
```

Basic Network Elements (Software)

❖ ARP OPERATION



a. ARP request is broadcast




b. ARP reply is unicast

Basic Network Elements (Software)

Internet Of Things (IOT)



- Rapidly growing technology
- Aims connect all devices to the existing Internet infrastructure.
- "things" that sense and collect data and send it to the internet.
- (Eg:- coffee maker, A.C, Washing Machine, Ceiling Fan, lights , any thing) having sensors can be connected with internet.
- PRACTICAL APPLICATIONS:-
Smart Homes -Smart Cities-Energy - Environment monitoring- healthcare- Management



Kuva 1. Internet of Things. Lähde: Huffington Post

Basic Network Elements (Software)

TCP/IP Protocol Architecture




Basic Network Elements (Software)

TCP Characteristics

- Transmission Control Protocol
- Transport layer protocol
- Use port numbers
- Reliable (Acknowledgement of receipt)
- **Connection oriented**(synchronization)
- **Full duplex**
- Error control(Error checking(checksum)
- **Flow control**
 - Data-recovery features
 - Sequencing of data packets




TCP Header




Basic Network Elements (Software)

ESTABLISHING A CONNECTION



Basic Network Elements (Software)


THREE-WAY HANDSHAKE



CTL = Which control bits in the TCP header are set to 1


Basic Network Elements (Software)

Flow Control




Basic Network Elements (Software)

TCP Acknowledgment




Basic Network Elements (Software)

Fixed Windowing



Basic Network Elements (Software)

TCP Sliding Windowing




Basic Network Elements (Software)

UDP Characteristics

- User Datagram Protocol / Transport layer protocol
- Process to process communication
 - Use port numbers
- **Connectionless** (no notification)
- Unreliable
- **Perform very limited error checking**
- Very simple using a minimum of overhead
- Provides best-effort delivery
 - The data may be dropped due to:
 - Routing Error,
 - Duplicate data due to redundancy
 - Data loss in its way due to TTL.
- **Has no data-recovery features**

UDP Header



3.0 IP - 956


Basic Network Elements (Software)

TCP (Reliable) vs. UDP (Best-Effort Comparison)

	Reliable	Best-Effort
Connection Type	Connection-oriented	Connectionless
Protocol	TCP	UDP
Sequencing	Yes	No
Uses	<ul style="list-style-type: none">▪ E-mail▪ File sharing▪ Downloading	<ul style="list-style-type: none">▪ Voice streaming▪ Video streaming

Basic Network Elements (Software)

Mapping Layer 4 to Applications




Port Numbers

- **Well Known ports**
 - Range from 0 to 1,023 are assigned and controlled by ICANN
- **Registered ports**
 - Range from 1,024 to 49,151 not assigned or controlled by ICANN but can be registered at ICANN to avoid duplication
- **Dynamic ports**
 - Range from 49,152 to 65,535 are neither controlled nor registered

Basic Network Elements (Software)

Socket Address




Basic Network Elements (Software) - LAB

❖ NETSTATE

Netstat –n
netstat -a

To know session and ports on your device



The screenshot shows a Windows Command Prompt window titled "Command Prompt". The command "netstat -n" was entered, followed by "Active Connections". The output lists 14 TCP connections, all in ESTABLISHED state, between local address 127.0.0.1 and foreign address 127.0.0.1 on various ports.

Proto	Local Address	Foreign Address	State
TCP	127.0.0.1:40000	127.0.0.1:49673	ESTABLISHED
TCP	127.0.0.1:49673	127.0.0.1:40000	ESTABLISHED
TCP	127.0.0.1:52786	127.0.0.1:60014	ESTABLISHED
TCP	127.0.0.1:52787	127.0.0.1:60012	ESTABLISHED
TCP	127.0.0.1:60010	127.0.0.1:60158	ESTABLISHED
TCP	127.0.0.1:60012	127.0.0.1:52787	ESTABLISHED
TCP	127.0.0.1:60014	127.0.0.1:52786	ESTABLISHED
TCP	127.0.0.1:60014	127.0.0.1:60157	ESTABLISHED
TCP	127.0.0.1:60154	127.0.0.1:62522	ESTABLISHED
TCP	127.0.0.1:60156	127.0.0.1:62522	ESTABLISHED
TCP	127.0.0.1:60157	127.0.0.1:60014	ESTABLISHED
TCP	127.0.0.1:60158	127.0.0.1:60010	ESTABLISHED
TCP	127.0.0.1:62522	127.0.0.1:60154	ESTABLISHED

Thanks